


Installation and Maintenance Instructions

ATLAS

WHEEL BLOCK SYSTEM




RB 315



KARL GEORG

Foreword

Thank you very much on deciding on a product from the company KARL GEORG.

 **These Installation and Maintenance Instructions contain all information required for the installation, as well as for safe operation and maintenance of the wheel blocks. Before installation and commissioning, carefully read these. The operating personnel must have access to these instructions at all times.**

KARL GEORG accepts no liability for damage and operating malfunctions that result from the non-observance of these Installation and Maintenance Instructions.


Intended Use

The KARL-GEORG wheel blocks are used in conveyor-related systems, as well as in the overall field of machine construction and enable flexible transportation tasks. Due to the all-round processed mounting surfaces and the connection elements available as an option, there are numerous connection options. The drive shafts can be designed to adapt to slip-on gear mechanisms of all makes.

The Wheel block body comprises of two halves of a precise fitting, machined housing attached by bolts. Thereby, the expendable “crane wheel” and the spherical roller bearing can be quickly and economically replaced using commercially available tools.

Materials: Crane wheel EN-GJS-700 (GGG-70)
Housing EN-GJS-400 (GGG-40)

The connection holes in the housing and the associated connection elements provide flexible options for precise connection. During delivery, plastic plugs protect all connection bore holes.

 The plastic plugs can be used at temperatures of -40 ° C to +60 ° C. If the wheel blocks are used outside this temperature range, as well as in the ATEX area, the plastic plugs must be removed before commissioning.

Colour

Standard: The wheel block housing and crane wheel body are provided with an anthracite-coloured 1-K corrosion protection primer at the works. These feature good paintability, corrosion-resistance and resistance to the weather.

Special colour: On request, the wheel blocks can be designed with a primer, intermediate and top coat.

Predictable incorrect use

Non-observance of these Installation and Maintenance Instructions and/or the main catalogue can result in an impermissible use of the wheel block system. Thereby, under unreasonable conditions, malfunctions, failure or risk to life and limb can occur.

The situations given below result in, e.g. impermissible use:

- Design:
 - Impermissible or unconsidered load peaks
 - Unconsidered extreme ambient conditions
 - Impermissible application temperatures
- Installation:
 - Incomplete use of installation elements
 - Using installation elements from third parties
 - Insufficient alignment of the wheel blocks to the track
- Maintenance:
 - Non-observance of the lubrication intervals under extreme conditions
 - Non-observance of the tightening torques for the connection bolts and/or the inspection intervals.

Maintenance

Because of the technical construction of the KARL GEORG wheel blocks, under normal operating conditions, they are fundamentally maintenance-free.

Bolted fittings

Check the connection bolts for the drive shafts using a torque wrench after the initial 3 - 6 operating hours or approx. 100 load reversals (tightening torque 360 Nm).

After a further three months operating time, tighten all bolted fittings to the specified tightening torque, subsequently, as required in accordance with the conditions of use and operating conditions, however, a minimum of once a year (refer to BGV D6 UVV cranes).

Roller bearings

The spherical roller bearings are lubricated.
Lubricating intervals adapted to the respective conditions of use.

Before delivery, the roller bearings are lubricated with the following greases:

- a) Series**

Product: Multifak EP 2
Manufacturer Texaco
- b) Higher temperatures $\leq 200\text{ }^{\circ}\text{C}$**

Product: OKS 424
Manufacturer OKS

Equivalent lubricants can be used, however, compatibility with the original lubricant must be ensured.

- c) For operation in the Ex-area, the special grease OKS 464 (manufacturer OKS) must be used.**

After commissioning, slight escape of grease can occur at the seals, these should be removed and disposed of in an environmentally-friendly manner!

Material fatigue/crane wheel wear

Depending on the individual case, wheel block and drive shafts must be checked at regular intervals for corrosion, material fracture (in particular fracture of shafts) and for correct alignment.

The running surface and wheel flanges must be checked a minimum of every three months for wear and/or damage.
The crane wheel unit must be replaced when one of the following limit values is attained:




Table of limit values for wear

Size of crane wheel (RB ...)	smallest wheel flange width a	smallest crane wheel-Ø d1
160	7,0	153,5
200	8,5	193
250 / 250-V	9,5	242
315	11	307
400	13	392

On request, wheel blocks can be sent for servicing.

In order to minimize wear on the crane wheel, the wheel blocks should be correctly aligned and the rail free of contamination. Furthermore, on request, there is the option of hardening the running surfaces and inner surface of the wheel flanges so that they are anti-slip, in order to increase the service life of the crane wheels.

Storage

- The wheel blocks must be stored in a dry place
- The crane wheels must be rotated every six months
- Before use, the wheel blocks must be lubricated whilst rotating the crane wheel

Possible faults and rectification

- Increased wear on the running surface and/or wheel flange
- Running noises

Track contaminated?

The rail should be protected from excessive contamination, e.g. by regular cleaning. As required, a rail cleaner should be used.

Misalignment of the wheel blocks?

Wheel blocks should be checked at regular intervals for correct alignment. If misaligned, realignment is required.

If a bearing is defective, the complete crane wheel unit must be checked and the defective parts replaced. Here, observe the chapter for Removal and Installation of the wheel block. On request, the defective wheel blocks can be sent for servicing.

Permissible wheel loads

Size of crane wheel (RB ...)	Wheel load in kg*
160	6.800
200	10.000
250	12.800
250-V	16.000
315	22.000
400	30.000

*the a.m. values apply to the use under optimum conditions. At temperatures >150 °C, the wheel loads reduce.

Weight of wheel block

Size of crane wheel (RB ...)	Weight in kg
160	ca. 21
200	ca. 33
250	ca. 52
250-V	ca. 57
315	ca. 90
400	ca. 165

Roller bearings

Series

Sealing is carried out on both sides by special seals made from POM. The spherical roller bearings are lubricated.

Can be used at temperatures of 30 °C to +90 °C. (temporarily up to 130 °C).

Special sealing

Sealing is carried out on both sides using Nilos rings with additional protective discs made from steel. The spherical roller bearings are lubricated.

Used for extreme environmental conditions (dust, heat, moisture etc.) at temperatures from 30 °C to 140 °C.

It is possible to lubricate the wheel blocks.
Lubricating intervals adapted to the respective conditions of use.

Higher temperatures

Sealing is carried out on both sides using Nilos rings with additional protective discs made from steel. The spherical roller bearings are lubricated using OKS 424 high temperature grease.

Can be used at temperatures of -25 °C to + 200 °C.

Lubrication intervals and quantity of grease for high temperature bearing grease Type OKS 424

Reduction factors:

Dust and humidity	x	0,4 - 0,7
Vibration and oscillations	x	0,4 - 0,7

Lubrication as a consequence of heat influence of

110°C	after	16.000 hours
125°C	after	8.000 hours
140°C	after	4.000 hours
155°C	after	2.000 hours
170°C	after	1.000 hours
185°C	after	500 hours
200°C	after	250 hours


Minimum quantity of grease for each bearing: 14 cm³

ATEX


Sealing is carried out on both sides using Nilos rings with additional protective discs made from steel. The spherical roller bearings are lubricated using OKS 464 (electrically conductive) high temperature grease.

Suitable for temperatures of -20 °C to +60 °C.

Lubrication is carried out depending on the temperature and operating time of the wheel blocks.



Spherical roller bearing 222 18



Spherical roller bearing 222 18

ATEX (EX-protection)

Application in potentially explosive areas in accordance with the Directive 94/9/EC ("ATEX 95")



Permitted application

The application of wheel blocks in potentially explosive areas is only permissible when the following instructions are observed, in order to ensure safe and correct application.

Drive speed

Relative speeds of the wheel blocks within the **Zone 1 and 21** of less than **1 m/s** are permitted. Monitoring of the travel speeds should always be carried out in Zone 1 and 21. For operation with a frequency converter in Zone 2 and 22 and travel speeds of more than 1 m/s, speed monitoring of the crane wheels must be carried out.

Electrical voltage

The wheel blocks must be permanently conducted to the complete system, the complete system can be individually earthed. If that cannot be ensured under all circumstances, additional methods of ensuring the electronic contact must be installed (e.g. contact brushes). The equipotential bonding must be regularly checked by the operating company. The operating company and equipment manufacturer must ensure sufficient protection against straying currents.

Drive

In potentially explosive areas, only Ex-protected motors with special Ex-protected frequency converters must be operated under consideration of the interconnection.

Track

Pay attention to the material used for the tracks. No light metals should be used. Furthermore, the material must be low-sparking, in the terms of Directive 94/9/EC and non-corrosive.

Temperature

For operation in Zone 1 and 21, monitoring of the bearing temperature must be ensured. During braking, friction heat can be generated. Possibly must be measured after installation of the wheel blocks in the complete system.

Prevention of accident

Fundamentally, make sure that no collisions can occur whilst travelling. Impacting obstacles at high speeds should be unconditionally prevented. Possibly protection systems to prevent accidents must be installed. Accident prevention can be attained by using, e.g. light barriers or end limit switches. In any event, provide an adequate brake path.

Identification

The wheel block from the company KARL GEORG represents an "incomplete machine" in accordance with the Machinery Directive 2006/42/EC (definition refer to Article 2 Letter g).

Thus, wheel blocks from the company KARL-GEORG are not committed to having the "CE" mark and only have the ATEX-Directive 94/9/EC ("ATEX 95"), if these are approved for potentially explosive areas.

Zone 1 and 21:



Zone 2 and 22:



Identification in accordance with RL94/9/EG Appendix II Para.1.0.5

ATEX (EX-protection)

Application in potentially explosive areas in accordance with the Directive 94/9/EC ("ATEX 95")



Design measures

The wheel block is only approved for Zones 1/21 and 2/22 with the mark in accordance with the ATEX-Directive.

If using the wheel blocks in potentially explosive areas, these must be designed with special seals (refer to Page 5) and using electrically conductive grease OKS 464.



Plastic plugs for application in ATEX-area are not permitted.

In addition, only applicable for Zone 1 and 21:

- The cellular plastic buffers PU 70...210 are not permitted.
 ↳ A material must be used that can verify a surface resistance of less than 1 GΩ
- The speed must be monitored, particularly when operating using frequency converters.
- Accident prevention can be attained by using, e.g. light barriers or end limit switches.
 In any event, provide an adequate brake path.
- The bearing temperatures must be monitored.

Maintenance (supplement ATEX)

In addition to the chapter maintenance (refer to Page 3) observe the following instructions about the application in potentially explosive areas:


- Tracks must be cleaned at regular intervals using an anti-static brush.
- The forming of corrosion on the tracks must be prevented.
- No potentially explosive atmospheres must be present for maintenance tasks or any adjustment necessary !
- One-sided starting of the wheel sets against the track system must be prevented.



Note:



**The ATEX-Directive is only applicable for a temperature range of -20 °C to +60 °C.
 As necessary, at higher ambient temperatures, measurements must be carried out at the wheel blocks.**

Installation dimensions of the wheel block RB 315




Wheel block, driven

Wheel block, not driven




RBA 315



Special sealing
higher temperatures


RBN 315





Part No.	Quantity	Designation
1	2	Housing halves RB 315, EN-GJS-400
2	4	Locking pin 28 x 50, 55 Si7, DIN EN ISO 8752
3	4	Hexagon head bolt M 16 x 160, DIN 931, 10.9
4	4	Disc spring 31,5 x 16,3 x 2, DIN 2093
5	4	Safety nut M16 - 10
6	2	Grease nipple C R1/8" DIN 71412
7	1	Crane wheel RBA 315, EN-GJS-700
8	1	Crane wheel RBN 315, EN-GJS-700
9	2	Sealing disc, inner, POM
10	2	Self aligning roller bearing 222 18 DIN 635-2
11	2	Sealing disc, outer, POM
12	2	Locking bolt M 16 x 80, 12.9
13	1	Drive shaft
14	1	Circlip DIN 471/DIN 983
15	1	Feather key DIN 6885/1
16	2	Protective disc, inner, C 45
17	2	Nilos ring 222 18 AV
18	2	Nilos ring 222 18 IV
19	2	Protective disc, outer, C 45

Top connection KA 315.1

Direct connection as bolted fitting (for e.g. roller profiles, welded construction etc.)



Hole pattern of connection design for precise fitting variant



Order example:


1 Set KA 315.1

1 Set of connection elements for Top connection KA 315.1 consist of:

- 8 Locking bolts
M 16 x 45, 10.9
- 8 Locking pins 18.5 x 1 x 14

Locking bolt
M 16 x 45
(Tightening
torque
330Nm)

Locking pin 18,5 x 1 x 14



Connection options

- Precise fitting direct connection: Connection option **1** (see figure)
- Adjustable direct connection: Connection option **2**

The connection option 1 requires a precise agreement of the hole pattern on the wheel block and connection design (refer to Fig.)! In order to prevent positional errors and, thus, premature wear of the crane wheels, the attaching surfaces must be exactly aligned with the connection holes on the system.

If the connection holes cannot be exactly produced, connection must be carried out in accordance with connection option 2 (hole pattern, refer to Page 11).

Installation procedure

Connection option 1:


1. Position the wheel block against the connection holes of the connection design.
2. Insert the locking pins 18.5 x 1 x 14.
3. Install locking bolts M16 x 45 (tightening torque 330 Nm).

Connection option 2:

1. Position the wheel block against the connection holes of the connection design.
2. Install locking bolts M16 x 45 hand tight.
3. Exactly align the wheel block on the system, in order to prevent positional errors and, thus, premature wear of the crane wheels. Alignment can be carried out using the machined side surfaces of the wheel block.
4. Tighten locking bolts M16 x 45 (tightening torque 330 Nm).
5. Drill the holes for the locking pins and insert the locking pins (e.g. 8 x 24 in accordance with DIN EN ISO 8752). Pinning is not permitted in the area of the connection bolt of the wheel blocks (refer to Fig. Page 11)!

Top connection KA 315.2

Direct connection as bolted fitting (for e.g. roller profiles, welded construction etc.)



Order example:

1 Set KA 315.2

1 Set of connection elements for Top connection KA 315.2 consist of:

- 8 Grub screws M16x105 - 10.9ZT
- 8 Safety nuts M16 - 10
DIN EN ISO 7042
- 8 Discs 17 DIN 6340
- 4 Locking pins 8x24
DIN EN ISO 8752
for adjustable connection
- 8 Locking pins 18,5x14
for precise connection

Longer grub screws are available on request.

Connection options

- Precise fitting direct connection: Connection option 1
- Adjustable direct connection: Connection option 2 (refer to Fig.)

Connection option 1 requires the hole patterns on the wheel block and connection design to match exactly (hole pattern Page 10)! In order to prevent positional errors and, thus, premature wear of the crane wheels, the attaching surfaces must be exactly aligned with the connection holes on the system.
If the connection holes cannot be exactly produced, connection must be carried out in accordance with connection option 2.

Installation procedure

Connection option 1:

1. Install the wheel block with bonded grub screws in the connection holes for the connection design.
2. Insert the locking pins 18.5 × 1 × 14
3. Install the safety nuts M16 with discs (tightening torque 245 Nm).
When doing this, hold the grub screws across the width across flats!

Connection option 2:


1. Install the wheel block with bonded grub screws in the connection holes for the connection design.
2. Install the safety nuts M16 with discs and hand tighten.
3. Exactly align the wheel block on the system, in order to prevent positional errors and, thus, premature wear of the crane wheels. Alignment can be carried out using the machined side surfaces of the wheel block.
4. Tighten safety nuts M16 (tightening torque 245 Nm). Hold the grub screws across the width across flats!
5. Drill Ø8 H13 holes for the locking pins 8 × 24 and insert the locking pins.
Pinning is not permitted in the area of the connection bolt of the wheel blocks (¹⁾ see figure)!

Side connection WA 315


Lateral connection option for low construction designs

Connection option 1:

Connection design is accessible from both sides




Schnittansicht




Connection option 2:

Connection design and hollow profile is not accessible from inside




Schnittansicht




Connection option 1:

Through-hole Ø 40^{H12}



Connection option 2:

Blind bore hole Ø 40^{H12} x 20 deep with M 20 thread



1	Set of connection elements for Side connection WA 315 composed of:	Order example:
4	Flanged bushings 40, bonded at the factory	1 Set WAA 315 (Side connection on the drive side)
4	Locking bolts M 20 x 80, 12.9	
4	Safety nuts M 20 DIN EN ISO 7042	1 Set WAN 315 (Side connection on the non-driven side)
4	Discs 21	
		1 Set WA 315 (Side connection on the non-driven- wheel block RBN)

Installation procedure

The connection surface of the connection design for the wheel block must be so even that the wheel block cleanly rests on the machined surfaces (if necessary, machine).
In order to prevent positional errors and, thus, premature wear of the crane wheels, the connection surfaces must be exactly aligned on the system.

Connection option 1

(Connection design is accessible from both sides)

1. Install the wheel block with the four bonded flanged bushings into the locating holes $\varnothing 40^{H12}$ and press against the connection design.
2. Use a socket wrench to insert locking bolts M 20 x 80 through the holes in the opposite drilled holes in the housing in the wheel block.
3. Install the $\varnothing 21$ discs and the M 20 safety nuts.
4. Use a torque wrench and tighten the safety nuts.
Torque: 480 Nm


Connection option 2

(Connection design is only accessible from the front)

1. Install the wheel block with the four bonded flanged bushings into the locating holes $\varnothing 40^{H12}$ and press against the connection design.
2. Use a socket wrench to screw locking bolts M 20 x 80 through the holes in the opposite drilled holes in the housing in the wheel block.
3. Use a torque wrench and tighten the locking bolts.
Torque 550 Nm

Pin connection BA 315.1

Installation variant with pin connection (hollow profiles, floating levers, etc.)



- 1 Set of connection elements for Pin connection BA 315.1 consist of:
- 2 Bolts Ø 40 x 235
- 4 Circlips 40 x 1,75 DIN 471
- 4 Spacer bolts
- 16 Adjusting washers 40x50x0,5 DIN 988

Order example:
1 Set **BA 315.1**

In order to prevent positional errors and, thus, premature wear of the crane wheels the holes Ø 40^{D9} for attaching the wheel block must be exactly drilled to one another and precisely align the wheel block in the connection design. Before setting the track, or at initial installation, the wheel block must be relieved.


You set the track or centre the wheel block in the connection design by changing the shims onto the spacer bolts.

Installation procedure

1. Determine the thicknesses of the shims and insert the spacer bolts into the bottom four Ø 40 drilled holes of the wheel block using the appropriate number of shims.
2. Insert the wheel block as tightly as possible into the connection design.
3. Use two bolts to attach the connection design to the wheel block through the top Ø 40 holes.
4. Install circlips to axially secure the bolt.

Pin connection BA 315.2

Installation variant with pin connection (hollow profiles, floating levers, etc.)




- 1 Set Of connection elements for Pin connection BA 315.2 consist of:
 - 2 Bolts $\varnothing 40 \times 235$
 - 4 Circlips $40 \times 1,75 \text{ DIN } 471$
 - 4 Flanged bushings with internal thread (bonded)
 - 4 Locking bolts M 16 x 50, 10.9 (coated)
- Order example:
1 Set **BA 315.2**

In order to prevent positional errors and, thus, premature wear of the crane wheels the holes $\varnothing 40 \text{ D9}$ for attaching the wheel block must be exactly drilled to one another and precisely align the wheel block in the connection design. Before setting the track, or at initial installation, the wheel block must be relieved.

Installation procedure

1. Insert the wheel block in the connection design.
2. Use two bolts to attach the connection design to the wheel block through the top $\varnothing 40$ holes.
3. Install circlips to axially secure the bolt.
4. Install two M16 \times 50 adjustment screws on one side through the holes in the connection design into the wheel block. By tightening the adjusting screws (tightening torque max. 280 Nm), pull the wheel block into the required (horizontal) position.
Option for correction: Release the adjustment screws along the correction path, install the other two adjustment screws on the opposite side and pull the wheel block back into position.
5. When the required position is reached, tighten all adjustment screws (tightening torque 280 Nm max.)

Installation of cellular plastic buffer



Included in the scope of delivery:

- 1 Cellular plastic buffer
- 1 Grub screw
- 1 Retained nut

Order example:

1 Cellular plastic buffer **Pu 130**


Installation procedure

1. Route the M12 retained nut from the inside to the corresponding drilled hole and draw it from outside into the wheel block housing using an M 12 bolt.
2. Screw the M12 grub screw into the buffer.
3. Screw the buffer into the retained nut in the wheel block with the grub screw.

Nominal size	d1	d2	l1	Energy absorption	Spring travel	Final force	Weight per unit
				[kJ] ¹⁾	[mm] ¹⁾	[kN] ¹⁾	[kg]
Pu 70	70	65	66	0,25	55	7	0,3
Pu 100	100	95	100	0,80	74	40	0,6
Pu 130	130	122	120	1,60	86	54	1,0
Pu 160	160	155	150	4,20	120	110	2,1

¹⁾ These values apply to impact forces, which occur during crane operation (V = 120 m/min)

Installation der Drive shaft



Included in the scope of delivery:

- 1 Drive shaft
- 2 Locking bolt
- 1 Circlip or Feather key

For ordering, state the gearbox type, shaft journal and manufacturer information.

Order example:

1 Drive shaft 315
FV 77 DT/DV – W 50 – SEW


Installation Procedure

To prevent fretting corrosion, the drive shaft is electrogalvanized and the conical seat in the crane wheel has a bonded coating.

Attention! Do not damage the coating of the conical seat, if damaged replace (Molykote D 321 R spray on thin and uniform).

1. Insert the drive shaft into the crane wheel.
2. Install the connection bolts
3. Insert the drive shaft into the cone by tapping it lightly with a hammer (aluminium hammer, copper bolt) and tighten the connection bolt using a torque wrench (tightening torque 360 Nm) (Repeat the procedure).
4. Apply a coat of roller bearing grease in the area of the slip-on gear mechanism.
5. Push on the slip-on gear mechanism and attach as specified by the manufacturer.
6. After 3 to 6 operating hours or approx. 100 load reversals, use a torque wrench and tighten the connection bolts (tightening torque 360 Nm).

Removal of the drive shaft




Removal procedure

It is necessary to use a special set screw M20 to easily remove the drive shafts.

1. Remove the connection bolt (refer to the figure "Installation of the drive shaft").
2. Release the slip-on gear mechanism at the torque support and pull from the drive shaft.
3. Use a ring spanner and insert special set screw M 20 into the crane wheel (lubricate thread and point of bolt with grease). Thereby, the drive shaft is pressed from the cone.

Installation and removal of the central drive



Included in the scope of delivery:

- 1 Drive shaft ZAA
- 1 Drive shaft ZAM
- 4 Locking bolts
- 2 Couplings with clamping sleeves
- 1 Connecting shaft

When ordering, always state the gearbox type or the splined-shaft profile and the average track dimension L.


Order example:
1 Central drive 315
FV 77 DT/DV - W 50 - SEW - 2000

Installation procedure

1. Install the drive shafts in accordance with the instructions "Installation of the drive shaft".
2. Apply a coat of roller bearing grease to the drive shafts and connecting shaft in the area of the slip-on gear mechanism and couplings.
3. Push on the slip-on gear mechanism and attach as specified by the manufacturer.
4. Push the couplings onto the connecting shaft on both sides (refer to Fig. above)
5. Place the connecting shaft with couplings between the drive shafts and push the couplings half way onto the drive shafts.
6. Secure the couplings by hammering in the Ø 8 clamping sleeves.

Removal is carried out in the reverse order.


Removal of the wheel block



Removal procedure

1. Lay down the wheel block on the head side, or clamp in a vice.
2. Remove four connection bolts.
3. Screw in two M 16 × 40 screws approx. 20 mm into one half of the housing at the front.
4. The halves of the housing are separated by lightly tapping on both assembly screws alternately. As soon as a gap appears between both halves of the housing, the wheel block housing can be also prised apart using a suitable tool.
5. Remove the halves of the housing (1) from the self-aligning roller bearings.
6. Remove the sealing discs (11) halves of the housing.
7. Using a suitable extractor, pull the self-aligning roller bearing (10) from the hubs of the crane wheel.
Thereby, the extraction hook of the extractor should be inserted between the bearing and seal disc (9).
8. Replace the self-aligning roller bearing and seal discs.

Dismounting device




Further information and details of pricing and delivery periods are available on request!


Installation of the wheel block

Installation procedure

1. Place the crane wheel (7) and (8) horizontally.
2. Install the inner seal disc (9) with the convex outer diameter upwards.
3. Press on the self-aligning roller bearing (10).



4. Turn over the crane wheel and assemble on the other side of the hub as in 2. and 3.
 5. Place one half of the housing (1.1) on the flank connection surface.
 6. If not installed, insert in the 4 locking pins 28×50 (2).
 7. Install the outer seal disc (11.1) with the convex inner diameter upwards.
 8. Install the self-aligning roller bearing with crane wheel into the bore of the housing.
 9. Place the outer seal disc (11.2) on the self-aligning roller bearing with the convex inner diameter upwards.
 10. Push the second half of the housing (1.2) onto the self-aligning roller bearing until the housing halves touch the locking pins.
 11. Using a plastic or aluminium hammer and tap in the top half of the housing (1.2) in the area of the locking pins, or use an assembly press to press it in.
 12. Install four M 16 \times 160 connection bolts (3, 4, 5).
 - Attention! Pay attention to the correct position of the disc spring (4) below the bolt head.
 13. Use a torque wrench to tighten the hexagon-headed bolts (3) (tightening torque 260 Nm).
 14. Lubricate the self-aligning roller bearing through the existing lubrication nipple (6) until grease escapes at the seal discs.
- During the lubrication procedure, turn the crane wheel.



The wheel blocks with special sealing and for higher temperatures and/or ATEX are installed as previously described, however, instead of the plastic seal discs, Nilos rings (metal seals) and protective discs made from steel (Part 16 - 19) are installed.

Subsequently, lubricate roller bearings with suitable grease, refer to Page 3.

Produkt- und Kundeninformation *Product and customer information*

Beim Radblocksystem handelt es sich um eine einbaufertige Fahrenheit für förder technische Anlagen (z.B. Krane).
The wheel block system is a ready-to-install travel unit for conveyor systems (e.g. cranes).

Das Radblocksystem ist keine Maschine und dazugehöriges Produkt im Sinne der Richtlinie 2006/24/EG sowie der Verordnung 2023/1230.

The wheel block system is not a machine and associated product within the meaning of Directive 2006/24/EC and Regulation 2023/1230.

Das Radblocksystem ist als Komponente zu betrachten und ist konform mit den Anforderungen nachstehender Dokumente:

The wheel block system is to be regarded as a component and conforms to the requirements of the following documents:

- **DIN EN 13135 08/18** Krane – Sicherheit – Konstruktion – Anforderungen an die Ausrüstungen
Cranes – Safety – Design – Requirements for equipment
- **DIN EN 13001-3-3 02/15** Krane - Konstruktion allgemein - Teil 3-3: Grenzzustände und Sicherheitsnachweis von Laufrad/Schiene-Kontakten
Cranes - General design - Part 3-3: Limit states and proof of competence of wheel/rail contacts
- **DIN EN ISO 12100 03/11** Sicherheit von Maschinen – Allgemeine Gestaltungsleitsätze – Risikobeurteilung und Risikominderung (ISO 12100:2010)
Safety of machinery – General principles for design – Risk assessment and risk reduction (ISO 12100:2010)
- **DIN EN ISO 9001 11/15** Qualitätsmanagementsysteme - Anforderungen (ISO 9001:2015)
Quality management systems - Requirements (ISO 9001:2015)

Bei der Verwendung der Komponenten sind die Vorgaben / Hinweise der Montage-, Wartungsanleitung zu o.g. Komponente zwingend zu beachten!

When using the components, the specifications / instructions in the installation and maintenance instructions for the above-mentioned components must be observed!

D-57612 Ingelbach/Bhf., 14.03.25
Ort, Datum
Place, Date

Hees, Olaf
Geschäftsführung
CEO

Miesner, Thomas
Forschung + Entwicklung
Research + Development





Karl Georg GmbH
Karl-Georg-Straße 3
D-57612 Ingelbach-Bahnhof

T: +49 (0)2688 / 95 16 - 0
info@karl-georg.de
www.karl-georg.de

Subject to alterations by the manufacturer for the purposes of further technical development!

Thus, no claims can be derived from the information, figures and descriptions given in these operating instructions.

© 03/2025 Karl Georg GmbH

Reprinting, duplication or translation, also as extract, is not permitted without previous written consent of Karl Georg GmbH. All rights are expressly reserved for Karl Georg GmbH according to the copyright law. Subject to alterations

Printed in Germany